

The I2C master protocol

Netzer supports I2C master since version 1.2. The most data transactions are done transparently by Netzer. But a few protocol specifiers are implemented for handling the special states of I2C.

NULL - The termination character

The character `0x00` in the TCP/IP communication has special meaning in terminating any pending I2C transmission. If Netzer sends a `0x00` either the bus is busy, a bus collision occurred or a slave does not respond on address or data bytes. In the latter cases the bus is freed with a stop condition automatically. If Netzer receives `0x00` while a I2C transmission is pending, the transmission will be finished with a automatic generated stop condition.



If `0x00` should be sent via the I2C interface it must be escaped with a leading backspace. Therefore also the backslash itself must be escaped.

The start condition and the slave address byte

A start condition is automatically announced on the bus, if Netzer gets the first character via the TCP/IP serial socket. If an error occurs while announcing the start condition Netzer responds with a `0x00`. I2C protocol defines the very first byte after the start condition as slave address. Netzer sends a `0x00` via TCP/IP if no slave responds (ACK bit was '1'). Also a stop condition is initiated by Netzer. After the successful (means acknowledged) transmission of the slave address Netzer sends `0xFF` via TCP/IP.

General call address

The I2C general call address `0x00` addresses all slaves on the I2C bus. Sending `0x00` as the very first byte is allowed as an exception of the Netzer protocol. The escaping backslash **MUST** not be used.

The R/W bit

Netzer also checks the R/W bit (LSB) of the slave address character.

Master write

If the R/W bit is **cleared** a transmission from master to slave is initiated.

Each byte received by Netzer via the TCP/IP socket is directly sent to the slave (consider escaping!). In response Netzer sends via TCP/IP either '0xFF' as positive acknowledge (ACK bit was '0') or 0x00 as negative acknowledge (ACK bit was '1'). In case of a negative acknowledge Netzer initiates a stop condition on the bus.

Master read

If the R/W bit is **set** a transmission from slave to master is initiated (clock is generated by I2C master).

After the successful transmission of the slave address Netzer waits for further bytes on the TCP/IP socket. On receiving a byte via TCP/IP a byte is pulled from the slave and is sent via TCP/IP. In case the received byte is 0x00 the transmission is over and Netzer generates a stop condition on the bus. Any other value pulls the next byte from slave.

Repeated start

I2C supports repeated start. This symbol concatenates a stop and start condition while a I2C transmission is pending without freeing the bus inbetween.

The special character *s* (0x73) in TCP/IP stream initiates the repeated start on the bus. Therefore 0x73 must be escaped during normal stream transmission to Netzer. Exception to escaping 0x73 is the very first character (slave address) analog to the "General Call address" section.



Receiving 0x73 from Netzer has no special meaning but 0x73 and therefore will not be escaped!

From:

<http://mobacon.de/dokuwiki/> - **MoBaCon**

Permanent link:

<http://mobacon.de/dokuwiki/doku.php?id=en:netzer:i2c-master&rev=1419155800>

Last update: **2025/06/11 20:42**

